



R114 becomes open circuit
 R115 becomes a link
 U1 mounts in the slot for TS13
 D1 and D2 are optional but
 provide short-circuit
 protection.
 Rload is just there to satisfy
 SPICE: ignore.